

Sodastream

your home soda factory

• G100
• PU6001 PURE



USER MANUAL **BRUGERMANUAL** **NAUDOJIMO INSTRUKCIJA**
BRUKERMANUAL **ÄYTTÖOHJEET** **LIETOŠANAS INSTRUKCIJA**
BRUKSANVISING **KASUTUSJUHEND** **ИНСТРУКЦИЈА ПО ЕКСПЛУАТАЦИЈИ**

Sodastream

your home soda factory

UK:
Soda-Club Worldwide Trading Company
7 The Office Village
Cynnel Park, Forder Way
Pleatonrough PE7 9GX
Tel: 0800 085 8373
www.sodastream.co.uk

SOUTH AFRICA:
Soda-Club (SA) (PTY) Ltd.
Route 21 Corporate Park
48 Sovereign Drive
Irene ext 30, Centurion
Tel: 0800-06-22-91
www.sodastream.co.za

NEW ZEALAND:
SodaStream (New Zealand) Ltd.
PO Box 34521
Birkenhead, Auckland
Freecall: 0800 763 278
www.sodastream.co.nz

AUSTRALIA:
Soda-Club Australia Pty Limited
5 Keysborough Close
Keysborough, Victoria 3173
Tel: 1 800 005 199
www.sodastream.com.au

BALTIC STATES:
Empire Baltics, Pulkveža Brieža 41-209
LV-1045, Rīga, Latvia.
Tel: +371-673 21 205
www.sodastream.lv
www.sodastream.lt


NORWAY / NORGE:
Soda-Club Scandinavia AB
Tel: +47 800 30 095
info@sodastream.no
www.sodastream.no

FINLAND:
Maahanvilja: ETACAP OY
Vanha Porvooite 229
01380 Vanhaa
Tel: + 358 (0)9 4730 4421
www.sodastream.fi

www.sodastream.com


GETTING STARTED

Sätta igång
Start med
Sådan kommer du i gang
Tomli näin
Alustamine
Kaip pradėti
Ar ko sākt
Poprjok poboty



REPLACING AN EMPTY CYLINDER

Ersätta tom cylinder
Ärstatte en tom cylinder
Udskiftning af tom patron
Tyňňan patřulian vaihtaminen
Ballooni vaihtamine
Cilindri kehtimas
Tukšā cilindra nomēšana
Замѣна пусътого баллона



Dear customer

Thank you for choosing to buy one of our quality drinksmakers. For fullest satisfaction please read the user instructions c always happy to answer your questions, to contact your nearest Soda-Club/SodaStream office please visit www.sodastream.com.
PLEASE NOTE: Before exchanging an empty cylinder for a full one, please make sure to ask for a Soda-Club/SodaStream cylinder that fits your drinksmaker model. Do not try to fit a cylinder other than the type(s) suitable for your drinksmaker indicated on your drinksmaker's package.

G100 GETTING STARTED:

1. Remove the valve seal and cap from the cylinder valve. Screw the cylinder into the drinksmaker's head (A).
2. Place the drinksmaker head on the drinksmaker (B1). Press until you hear a click.
3. Fill the carbonating bottle with water to the fill line and chill.
4. Screw the bottle into the machine (D).
5. Press the carbonating button in short presses until you hear the buzz (E1). 3 buzzes will produce a standard fizz, additional presses will produce a stronger fizz.
6. Pull the carbonating bottle forward and unscrew to remove (F).

- #### PURE GETTING STARTED:
1. Remove the valve seal and cap from the cylinder into the drinksmaker's head (A).
 2. Place the drinksmaker head on the drinksmake until you hear a click (C).
 3. Fill the carbonating bottle with water to the fill line.
 4. Screw the bottle into the machine (D).
 5. Pull the carbonating lever in short pulls until you hear the buzz (E2). 3 buzzes will produce a standard fizz, add will produce a stronger fizz.
 6. Pull the carbonating bottle forward and unscrew to remove (F).

YOU CAN CHOOSE FROM A VARIETY OF FLAVOURS

- A wide range of flavours is available from Soda-Club/SodaStream, in bottles or in single servings. Please read mixing concentrate packaging labels before making drinks.
- Store flavours in a cool dark place.

G100 REPLACING AN EMPTY CYLINDER:

1. Remove the carbonating bottle from the drinksmaker (G).
2. Press the button located at the rear (H1).
3. Pull the drinksmaker head upwards (I1).
4. Unscrew the empty cylinder (J).
5. Return to step 1 + 2 of "Getting Started" above for closing and operating.

PURE REPLACING AN EMPTY CYLIND

1. Remove the carbonating bottle from the drinks
2. Press the button located at the rear (H2) and t
3. Pull the drinksmaker head upwards (I2).
4. Unscrew the empty cylinder (J)
5. Return to step 1 + 2 of "Getting Started" above operating.

IMPORTANT: Carbonate only when the drinksmaker is in the upright position. Carbonate only drinking water additives. Never carbonate an empty bottle.

BEFORE CALLING FOR SERVICE

1. If your drinksmaker does not carbonate:
 - If your cylinder is empty, exchange it. The weight of the full or empty cylinder is printed either on the cylinder or on its valve.
 - Check that the carbonating bottle has been filled up to the fill line.
 - Ensure that the drinksmaker is always in the upright position.
2. If your drinksmaker continues to release gas after the carbonating button has been released:
 - DO NOT REMOVE THE CYLINDER OR THE BOTTLE. LEAVE THE DRINKSMAKER IN THE UPRIGHT POSITION AND TOUCH THE DRINKSMAKER until escaping gas is no longer heard.
 - When gas is no longer being released, tilt the carbonating bottle and remove. Unscrew the cylinder and return it to your supplier.
 - Discard the carbonating bottle that was fitted into the drinksmaker and replace it with a new one.
 - In case of damage stop using the drinksmaker and contact the Customer Care Team in your country.
3. If a low hissing noise is heard from the drinksmaker during carbonation:
 - A slight hissing of gas may be heard when the drinksmaker is under pressure. This is quite normal and the noise will stop when the bottle is tilted and the pressure is released.
4. If, when fitting a new cylinder, gas leaks after you have screwed the cylinder to the drinksmaker:
 - There may be a pressure leak between the cylinder holder and the cylinder valve.
 - Screw the cylinder tighter into its holder. If this does not help, remove the cylinder immediately and check if the rubber seal ring is in place. If it is missing or has slipped out or place, replace it. You can obtain spare seals from your local Customer Care Team.
5. If water over-flows from the carbonating bottle during carbonation:
 - Have you over filled the carbonating bottle? Check the fill line and empty excess water if necessary. Are you pressing the cap too long? Use short, firm presses only.

LOOKING AFTER YOUR SYSTEM

CARING FOR YOUR DRINKSMAKER

Wipe your drinksmaker with a soft damp cloth. Do not wash in a dishwasher. Do not place or store the drinksmaker close to heat. Keep dry the drip tray at the bottom of the drinksmaker. The drip tray can be removed for cleaning if desired.

CARING FOR YOUR SODASTREAM CARBONATING BOTTLES

The carbonating bottles designed for your drinksmaker have a screw style fitting. Do not use any carbonating bottle approved by Soda-Club/SodaStream for use in your drinksmaker model, including, inter alia, bottles made by other or bottles made of glass.

After every use, rinse your carbonating bottle with lukewarm tap water with or without soap. For easy cleaning you may remove the base of the bottle by pulling the base downwards. Replace the base cup by pressing it onto the bottle from the bottom. Always use fresh cold drinking water and then place in the refrigerator for pre-chilled drinks. Do not allow materials such as ammonia based substances to come into contact with the bottle, as these may distort it.

Soda-Club/SodaStream Carbonating Bottles can be damaged by extremes of heat or cold (above 50°C or below 1°C) or by the bottle or its cap in the dishwasher, do not leave close to a direct heat source (oven or radiator) or in the car and do not place in the dishwasher. Soda-Club/SodaStream Carbonating Bottles may be placed in the dishwasher (once a week - 1 cycle) for cleaning. Look for the "dishwasher safe" indication on the bottle to know whether the bottle may or may not be placed in the dishwasher.

Check bottle caps occasionally for wear or cracks.

WARNING:

Every SodaStream Carbonating Bottle carries an expiry date - DO NOT use a bottle once this date has passed. Soda-Club/SodaStream Carbonating Bottles are subjected to stringent quality tests and with normal usage should reach their full life span. However, if you notice that your bottle has become worn, scratched, discoloured, lost its transparency or shape (DO NOT use it in your drinksmaker any longer). Please discard the bottle immediately and replace it with a new one.

SODA-CLUB/SODASTREAM CYLINDERS

The Soda-Club/SodaStream Cylinders are not for sale. These cylinders are the property of Soda-Club (CO₂) Ltd. or its affiliate in your country. The Soda-Club/SodaStream Cylinders are transferred to you when you purchase a suitable Soda-Club/SodaStream drinksmaker. The Soda-Club/SodaStream Cylinder is transferred to you when you purchase a suitable Soda-Club/SodaStream drinksmaker. When the cylinder is empty, exchange it for a full Soda-Club/SodaStream Cylinder at an authorised Soda-Club/SodaStream retailer or your local Soda-Club/SodaStream office.

Warning: Store cylinders in a cool place. Exposure to heat will cause the pressure in the cylinder to rise. As a safety precaution, the pressure inside the cylinder becomes too high. If this should happen, do not touch the cylinder, simply remove it from the machine. In such case, quick release of CO₂ causes the cylinder to become extremely cold. Do not touch the cylinder until it has warmed to room temperature.

NEVER TRANSPORT THE DRINKSMAKER WITH THE CYLINDER IN PLACE. DO NOT TAMPER WITH THE CYLINDER.

WARRANTY

Great care has been taken to ensure that your drinksmaker is delivered to you in perfect condition. However, if a fault should occur during a 24 months period following the date of purchase (please keep the receipt) due to a fault in the drinksmaker, we will either repair or replace (at our discretion) your drinksmaker free of charge.

Even if the fault has occurred due to misuse, we remain at your service but of course we would then request payment for the parts and labour. The repair will be carried out by an authorised Soda-Club/SodaStream Retailer or your customer care team. The efficient repair of your drinksmaker cannot be guaranteed to be carried out by any other party, and therefore, for the warranty to remain its valid, such repair or service through an authorised Retailer or customer care team.

If you have any questions, please call our Customer Care Team.

Soda-Club/SodaStream carbonating bottles

Your drinksmaker has been designed to operate with a suitable Soda-Club/SodaStream Carbonating Bottle (screw style fitting). Soda-Club/SodaStream Carbonating Bottles are designed to operate efficiently with any other bottle, and therefore for the warranty to remain its valid, please use only Soda-Club/SodaStream Carbonating Bottles in your drinksmaker.

Soda-Club/SodaStream cylinders

Your drinksmaker has been designed to operate with a suitable Soda-Club/SodaStream Cylinder, as explained in the user manual. It is not guaranteed to operate efficiently with other cylinders, and therefore for the warranty to remain its valid, please use only Soda-Club/SodaStream Cylinders filled by an authorised Soda-Club/SodaStream filling station, available from your local Soda-Club/SodaStream Retailer.

All Soda-Club/SodaStream products are subject to continuous development and specifications may change without notice.

MACHINE RATING

Maximum working pressure: 10 Bar / 145 Psi. Maximum allowed operating temperature: 40°C/104°F. Bottle capacity at fill range of 400 ml - 1.0 liter (varies by machine pack, may differ from images shown). Britnill bottle capacity will be in the range of 400 ml - 1.0 liter.